




# INTERNAL OVEN PARTS

For Model: RB262PXA1, RB262PXAQ1  
(Black) (Designer White)

30" ELECTRIC  
UNDERCOUNTER  
WALL OVEN



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# INTERNAL OVEN PARTS

For Model: RB262PXAB1, RB262PXAQ1  
(Black) (Designer White)

Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.		
1 880015 Back, Main	6 880023 Insulation, Back & Bottom (2)	13 880027 Bottom, Main
2 880016 Panel, Side (2)	7 880021 Hinge, Door (2)	14 880013 Tube, Oven Vent
3 880017 Support, Oven (2)	8 879451 Screw, 10-32 x 1/4 (4)	15 880010 Lamp, Oven
4 880018 Cover, Rear	9 880022 Insulation, Wrap	16 880009 Receptacle, Lamp
5 880019 Shield, Heat	10 880025 Black Model 880024 White Model	17 880012 Cover, Oven Lamp
	11 880026 Retainer, Insulation (2)	18 880011 Baffle, Broil 879356 Screw (6)
	12 879368 Probe, Oven	19 880006 Element, Broil
		20 880003 Support, Element
		21 880007 Element, Bake
		22 880008 Rack, Oven (2)
		23 879374 Pan, Broiler
		24 879375 Grill, Broiler Pan


## OPTIONAL PARTS NOT INCLUDED

Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION
<b>FOLLOWING PARTS NOT ILLUSTRATED</b>	<b><u>REFINISHING MATERIAL</u></b>	<b><u>ACCESSORY PARTS</u></b>
<b><u>SPLICING WIRES--25FT. LENGTH</u></b>	242756 Touch-Up 261582 Grease	241430 Foil, Aluminum Oven (18" x 25')
242828 Wire, Black 12 Ga. 150°C		3184477 Cleaner, Glass
242820 Wire, Black 14 Ga. 150°C		
242821 Wire, Blue 14 Ga. 150°C		
242822 Wire, Brown 14 Ga. 150°C		
242830 Wire, Brown 14 Ga. 200°C		
242823 Wire, Green 14 Ga. 150°C		
242824 Wire, Orange 14 Ga. 150°C		
242829 Wire, Red 12 Ga. 150°C		
242831 Wire, Red 14 Ga. 200°C		
242826 Wire, White 14 Ga. 150°C		
242827 Wire, Yellow 14 Ga. 150°C		
242832 Wire, Yellow 14 Ga. 200°C		

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OVEN DOOR PARTS

For Model: RB262PXAB1, RB262PXAQ1  
(Black) (Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OVEN DOOR PARTS

For Model: RB262PXAB1, RB262PXAQ1  
(Black) (Designer White)

Illus.	Part	
No.	No.	DESCRIPTION

NOTE: The screws and nuts required to attach a part are listed immediately following that part.


1		Handle, Door
	880033	Black Model
	880032	White Model
	880031	Screw, Handle (2)
2		Glass, Outer
	880029	Black Model
	880028	White Model
3		Clip, Glass
		Retainer (2)
	879380	Black Model
	879381	White Model
	879396	Screw (2)
4		Panel, Door
	880046	Black Model
	880045	White Model
		Screw, Panel (2)
	879320	Black Model
	879336	White Model
5	880039	Spacer, Glass (2)
6	880041	Seal, Foam (2)
7	880040	Channel, Air (2)
8	880037	Baffle, Door
	880004	Screw (10)
9	880038	Window Pak
14	880004	Screw (10)
15	880035	Liner, Door
16		Screw, Panel (2)
	879320	Black Model
	879336	White Model
18	880030	Spacer, Rubber (3)
19	879396	Screw, Clip (2)
20	880036	Insulation, Door
22	880034	Gasket, Door
23	880042	Seal, Glass
24	880044	Tape, Foil

## FOLLOWING PARTS NOT ILLUSTRATED

LIT879463	Installation Instructions
LIT879462	Use & Care Guide
LIT879464	Tech Sheet

# CONTROL PANEL PARTS


For Model: RB262PXAB1, RB262PXAQ1  
(Black) (Designer White)



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.			3		Trim, Side Left	6		Panel, Control
1	879466	Black Model	4381506		Black Model		879477	Black Model
	879465	White Model	4381504		White Model		879476	White Model
2		Screw, Trim (15)			Right	7	879478	Timer, Electronic
	879320	Black	4381507		Black Model		879479	Screw (4)
	879467	White	4381505		White Model	8		Switch, Oven Light
			4		Trim, Control Panel		879482	Black Model
				879473	Black Model		879481	White Model
				879472	White Model	9		Trim, Filler
			5		Trim, Top		879331	Black Model
				4381508	Black Model		879344	White Model
				4381509	White Model	10		Knob, Clock
							879484	Black Model
							879483	White Model
						11	879480	Shield, Timer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# BURNER BOX AND LATCH PARTS



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.			5	880000	Switch, Limit	16	879486	Insulation, Latch
1	880002	Block, Terminal		879480	Screw, Switch (2)	18	879485	Latch Assembly
2	879495	Retainer, Insulation (Top)	6	879494	Cover, Latch	19	879488	Switch, Latch
3	879496	Cover, Wire	9	879410	Clip, Handle		879487	Screw, Switch (2)
			10	879499	Housing, Fan	21	879490	Handle, Latch
			11	880020	Switch, Limit (Back of Range)		879423	Bolt
			12	879413	Fan Assembly		879491	Screw, Handle Knob, Latch
			13	879414	Cover, Fan	24		Handle
			14	879498	Plate, Conduit		879493	Black Model
			15	879497	Cover, Fan Housing		879492	White Model
						26	879489	Shield, Switch

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST